

Coby® Kyros™

Internet Tablet



MID7005-4G

Thank You

Congratulations on your purchase of a Coby® Kyros™ Internet Tablet. This guide provides help, to resolve the Applibs error message; please read it carefully and save it for future reference.

For Up-to-date information, and helpful tips, please visit the Coby website at www.cobyusa.com.



Appslib Fix

If you are encountering the following messages


"The application **Appslib** has stopped unexpectedly. Please try again. Then the option to "Force Close" in the box", the below procedure will fix the Appslib application.

NOTE:


**ALL DATA WILL BE DESTROYED DURING THE SYSTEM RECOVERY PROCESS.
PLEASE BE SURE TO BACKUP ALL YOUR DATA BEFORE PROCEEDING.**

Factory Data Reset


Step 1- Go to “Settings”




Step 2- Go to “Privacy”




Step 3- Select “Factory Data Reset”



Step 4- Select “Reset Device”



Step 5- Connect the unit to the computer using the USB cable and “Select” Erase Everything”



The following will occur:


- The screen will display COBY
- The screen will display Android
- The unit will reboot to the Menu screen

Step 6- The unit will prompt to calibrate. Hold stylus on the center of the target.

Repeat as the target moves around on the screen. ******DO NOT *** press Return or Home”.**

The unit will display “calibrate success” and will return to the main /home menu automatically. If for any reason the unit went into standby mode and the touch screen does not respond, reset the unit using a pin (see step 6 below).

	Name	Description
6	Reset key	Press to reset the tablet if it freezes or otherwise behaves abnormally. (Use a paperclip or other small object to gently press this key.)
7	SD/SDHC card slot	Load external SD or SDHC memory cards here.
8	Speaker	Speaker output is automatically disabled when headphones are connected to the player.



NOTES:

After the Factory Data Reset, do not launch the Applibs yet until:

- 1- You have configure your Wi-Fi
- 2- Check/enable “Unknown Sources”- Go to Settings, Application Setting. Done.

Support

If you have a problem with this device, please check our website at www.cobyusa.com for **Frequently Asked Questions (FAQ)** and product updates. If these resources do not resolve the problem, please contact Technical Support.

Coby Electronics Technical Support

Email techsupport@cobyusa.com

Web www.cobyusa.com

Phone 877-302-2629

Monday to Friday, 9:00AM–9:00PM EST